SANTO

Einbau-Kühlschrank electronic
Integrating Electronic Refrigerator

Gebrauchsanweisung
Operating instructions

Downloaded from Fridge-Manual.com Manuals

Sehr geehrte Kundin, sehr geehrter Kunde,

bevor Sie Ihr neues Kältegerät in Betrieb nehmen, lesen Sie bitte diese Gebrauchsanweisung aufmerksam durch. Sie enthält wichtige Informationen zum sicheren Gebrauch, zum Aufstellen und zur Pflege des Gerätes.
Bewahren Sie bitte die Gebrauchsanweisung zum späteren Nachschlagen auf. Geben Sie sie an eventuelle Nachbesitzer des Gerätes weiter.
Hinweis: Diese Gebrauchsanweisung ist für mehrere technisch vergleichbare Modelle mit unterschiedlicher Ausstattung bestimmt. Beachten Sie bitte nur die Hinweise, die Ihre Geräteausführung betreffen.

Mit dem Warndreieck und/oder durch Signalwörter **(Warnung!, Vorsicht!, Achtung!)** sind Hinweise hervorgehoben, die für Ihre Sicherheit oder für die Funktionsfähigkeit des Gerätes wichtig sind. Bitte unbedingt beachten.

1. Dieses Symbol leitet Sie Schritt für Schritt beim Bedienen des Gerätes.
2. ....

Nach diesem Zeichen erhalten Sie ergänzende Informationen zur Bedienung und praktischen Anwendung des Gerätes.

Mit dem Kleeblatt sind Tipps und Hinweise zum wirtschaftlichen und umweltschonenden Einsatz des Gerätes gekennzeichnet.

Erläuterungen zu Fachbegriffen, die in der Gebrauchsanweisung verwendet werden, finden Sie ganz zum Schluß im Abschnitt "Fachbegriffe".

Für evtl. auftretende Störungen enthält die Gebrauchsanweisung Hinweise zur selbständigen Behebung, siehe Abschnitt "Was tun, wenn ...". Sollten diese Hinweise nicht ausreichen, haben Sie jederzeit zwei Anlaufstellen, bei denen Ihnen weitergeholfen wird:

AEG DIRECT
INFO SERVICES 01 80 - 555 4 555*
* (Telekom 24 Pf/Min.)

Wir sind für Sie da:
montags bis freitags
8.00 bis 20.00 Uhr
samstags
10.00 bis 14.00 Uhr.

Nur für Deutschland

- Hier erhalten Sie Antwort auf jede Frage, die die Ausstattung und den Einsatz Ihres Gerätes betrifft. Natürlich nehmen wir auch gerne Wünsche, Anregungen und Kritik entgegen. Unser Ziel ist es, zum Nutzen unserer Kunden unsere Produkte und Dienstleistungen weiter zu verbessern.

Downloaded from Fridge-Manual.com Manuals

- Bei technischen Problemen steht Ihnen unser WERKSKUNDENDIENST in Ihrer Nähe jederzeit zur Verfügung (Adressen und Telefonnummern finden Sie im Verzeichnis Garantiebedingungen/Kundendienststellen). Beachten Sie dazu den Abschnitt "Kundendienst".

Gedruckt auf umweltschonend hergestelltem Papier
– wer ökologisch denkt, handelt auch so ...

Downloaded from Fridge-Manual.com Manuals

Inhaltsverzeichnis

Sicherheit 5
Entsorgung 7
Information zur Geräteverpackung 7
Entsorgung von Altgeräten 7
Transportschutz entfernen. 8
Aufstellen 8
Aufstellort. 8
Das Kältegerät braucht Luft 9
Einbau 9
Elektrischer Anschluss 10
Gerätebeschreibung. 11
Geräteansicht 11
Bedienblende 12
Tasten zur Temperatureinstellung 12
Temperaturanzeige 13
Luftfilter 13
Vor Inbetriebnahme. 15
Inbetriebnahme - Temperatur einstellen 15
TURBO COOLMATIC 16
TURBO COOLMATIC-Taste. 16
Gerät abschalten 17
Innenausstattung 17
Abstellflächen 17
Variable Innentür / Flaschenhalter. 18
LONGFRESH 0°C Kaltraum 18
Feuchte einstellen 19
Schubladen 19
Richtig lagern 20
Abtauen 23
Der Kühlraum taut automatisch ab 23
Reinigung und Pflege 23
Tipps zur Energie-Einsparung 24
Was tun, wenn 25
Abhilfe bei Störungen 25
Lampe auswechseln 26
Betriebsgeräusche 27
Bestimmungen, Normen, Richtlinien 27
Fachbegriffe 28

Downloaded from Fridge-Manual.com Manuals

⚠ Sicherheit

Die Sicherheit unserer Kältegeräte entspricht den anerkannten Regeln der Technik und dem Gerätesicherheitsgesetz. Dennoch sehen wir uns veranlasst, Sie mit folgenden Sicherheitshinweisen vertraut zu machen:

Bestimmungsgemäße Verwendung

- Das Kältegerät ist für die Verwendung im Haushalt bestimmt. Es eignet sich zum Kühlen von Lebensmitteln. Wird das Gerät zweckentfremdet oder falsch bedient, kann vom Hersteller keine Haftung für eventuelle Schäden übernommen werden.
- Umbauten oder Veränderungen am Kältegerät sind aus Sicherheitsgründen nicht zulässig.
- Sollten Sie das Kältegerät gewerblich oder für andere Zwecke als zum Kühlen von Lebensmitteln benutzen, beachten Sie bitte die für Ihren Bereich gültigen gesetzlichen Bestimmungen.

Vor der ersten Inbetriebnahme

- Überprüfen Sie das Kältegerät auf Transportschäden. Ein beschädigtes Gerät auf keinen Fall anschließen! Wenden Sie sich im Schadensfall bitte an den Lieferanten.
- Prüfen, dass das Gerät nach der Installation nicht auf dem Netzkabel steht.

  Wichtig: Beschädigte Versorgungskabel müssen durch ein Spezialkabel bzw. einen Spezialsatz ersetzt werden, die beim Hersteller oder den Kundendienststellen erhältlich sind.

Kältemittel

Das Gerät enthält im Kältemittelkreislauf das Kältemittel Isobutan (R600a), ein Naturgas mit hoher Umweltverträglichkeit, das jedoch brennbar ist.

- **Warnung** - Achten Sie beim Transportieren und Aufstellen des Gerätes darauf, dass keine Teile des Kältemittelkreislaufs beschädigt werden.
- Bei Beschädigung des Kältemittelkreislaufs:
  – offenes Feuer und Zündquellen unbedingt vermeiden;
  – den Raum, in dem das Gerät steht, gut durchlüften.

Sicherheit von Kindern

- Verpackungsteile (z. B. Folien, Styropor) können für Kinder gefährlich sein. Erstickungsgefahr! Verpackungsmaterial von Kindern fernhalten!

Downloaded from Fridge-Manual.com Manuals

- Ausgediente Altgeräte bitte vor der Entsorgung unbrauchbar machen. Netzstecker ziehen, Netzkabel durchtrennen, eventuell vorhandene Schnapp- oder Riegelschlösser entfernen oder zerstören. Dadurch verhindern Sie, dass sich spielende Kinder im Gerät einsperren (Erstickungsgefahr!) oder in andere lebensgefährliche Situationen geraten.
- Kinder können Gefahren, die im Umgang mit Haushaltsgeräten liegen, oft nicht erkennen. Sorgen Sie deshalb für die notwendige Aufsicht und lassen Sie Kinder nicht mit dem Gerät spielen!

Im Alltagsbetrieb

- Behälter mit brennbaren Gasen oder Flüssigkeiten können durch Kälteeinwirkung undicht werden. Explosionsgefahr! Lagern Sie keine Behälter mit brennbaren Stoffen, wie z.B. Spraydosen, Feuerzeug-Nachfüllkartuschen etc. im Kältegerät.
- **Warnung** - Keine Elektrogeräte (z. B. elektrische Eismaschinen, Rührgeräte etc.) im Kältegerät betreiben.
- **Warnung** - Um die Funktion des Gerätes nicht zu beeinträchtigen, dürfen die Lüftungsöffnungen der Geräteverkleidungen oder des Aufbaus von Einbaumöbeln nicht abgedeckt oder zugestellt werden.
- **Warnung** - Um den Abtauvorgang zu beschleunigen, keine mechanischen oder künstlichen Hilfsmittel verwenden, als die vom Hersteller empfohlenen.
- Vor Reinigungsarbeiten das Gerät grundsätzlich abschalten und den Netzstecker ziehen oder Sicherung in der Wohnung abschalten bzw. herausdrehen.
- Netzstecker immer am Stecker aus der Steckdose ziehen, nie am Kabel.

Im Störungsfall

- Sollte einmal eine Störung am Gerät auftreten, sehen Sie bitte zuerst in dieser Gebrauchsanweisung unter "Was tun, wenn ..." nach. Falls die dort aufgeführten Hinweise nicht weiterhelfen, führen Sie bitte keine weiteren Arbeiten selbst aus.
- Kältegeräte dürfen nur von Fachkräften repariert werden. Durch unsachgemäße Reparaturen können erhebliche Gefahren entstehen. Wenden Sie sich im Reparaturfall bitte an Ihren Fachhändler oder an unseren Kundendienst.

Downloaded from Fridge-Manual.com Manuals

Entsorgung

Information zur Geräteverpackung

Entsorgen Sie das Verpackungsmaterial Ihres Gerätes sachgerecht. Alle verwendeten Verpackungsmaterialien sind umweltverträglich und wiederverwertbar.

Zu den Werkstoffen: Die Kunststoffe können auch wiederverwertet werden und sind folgendermaßen gekennzeichnet:
>PE< für Polyäthylen, z. B. bei der äußeren Hülle und den Beuteln im Innern.
>PS< für geschäumtes Polystyrol, z. B. bei den Polsterteilen, grundsätzlich FCKW-frei.

Die Kartonteile werden aus Altpapier hergestellt und sollten auch wieder zur Altpapiersammlung gegeben werden.

Entsorgung von Altgeräten

Aus Umweltschutzgründen müssen Kältegeräte fachgerecht entsorgt werden. Dies gilt für Ihr bisheriges Gerät und - nachdem es eines Tages ausgedient hat - auch für Ihr neues Gerät.

Warnung! Ausgediente Altgeräte bitte vor der Entsorgung unbrauchbar machen. Netzstecker ziehen, Netzkabel durchtrennen, eventuell vorhandene Schnapp- oder Riegelschlösser entfernen oder zerstören. Dadurch verhindern Sie, dass sich spielende Kinder im Gerät einsperren (Erstickungsgefahr!) oder in andere lebensgefährliche Situationen geraten.

Entsorgungshinweise:

- Das Gerät darf nicht mit dem Haus- oder Sperrmüll entsorgt werden.
- Der Kältemittelkreislauf, insbesondere der Wärmetauscher an der Geräterückseite, darf nicht beschädigt werden.
- Das Symbol auf dem Produkt oder seiner Verpackung weist darauf hin, dass dieses Produkt nicht als normaler Haushaltsabfall zu behandeln ist, sondern an einem Sammelpunkt für das Recycling von elektrischen und elektronischen Geräten abgegeben werden muss. Durch Ihren Beitrag zum korrekten Entsorgen dieses Produkts schützen Sie die Umwelt und die Gesundheit Ihrer Mitmenschen. Umwelt und Gesundheit werden durch falsches Entsorgen gefährdet. Weitere Informationen über das Recycling dieses Produkts erhalten Sie von Ihrem Rathaus, Ihrer Müllabfuhr oder dem Geschäft, in dem Sie das Produkt gekauft haben.

Downloaded from Fridge-Manual.com Manuals

Transportschutz entfernen

Das Gerät sowie Teile der Innenausstattung sind für den Transport geschützt.

☞ **1.** Klebebänder links und rechts an den Türaußenseiten abziehen.

2. Alle Klebebänder sowie Polsterteile aus dem Geräteinnenraum entfernen.

Aufstellen

Aufstellort

Das Gerät soll in einem gut belüfteten und trockenen Raum stehen.

Die Umgebungstemperatur wirkt sich auf den Stromverbrauch und die einwandfreie Funktion des Gerätes aus.

Daher sollte das Gerät

- nicht direkter Sonneneinstrahlung ausgesetzt sein;
- nicht an Heizkörpern, neben einem Herd oder sonstigen Wärmequellen stehen;
- nur an einem Ort stehen, dessen Umgebungstemperatur der Klimaklasse entspricht, für die das Gerät ausgelegt ist.

Die Klimaklasse finden Sie auf dem Typschild, das sich links im Innenraum des Gerätes befindet.
Nachstehende Tabelle zeigt, welche Umgebungstemperatur welcher Klimaklasse zugeordnet ist:

Klimaklasse	für Umgebungstemperatur von
SN	+10 bis +32 °C
N	+16 bis +32 °C
ST	+18 bis +38 °C
T	+18 bis +43 °C

Direkter Einbau unter einem Kochfeld ist nicht zulässig. Die teilweise hohen Abstrahlungstemperaturen des Kochfeldes können das Gerät beschädigen.
Wird in der Nähe ein Kochfeld eingebaut, sind die zugehörigen Einbau- und Schutzvorschriften zu beachten. Durch die Vielzahl der möglichen Einbausituationen können hier keine detailierten Angaben erfolgen.
Eine Erwärmung des Kältegerätes ist durch ausreichenden Abstand und

Downloaded from Fridge-Manual.com Manuals

Einbringung einer geeigneten Wärmeschutzplatte zu verhindern. Die ordnungsgemäße Be- und Entlüftung des Kältegerätes muss gewährleistet sein.

Das Kältegerät braucht Luft

Integrierbare Modelle (i-Geräte)

Die Tür des Möbelschrankes dichtet die Einbaunische weitgehend ab. Deshalb muss bei i-Geräten die Belüftung durch eine Öffnung im Möbelsockel erfolgen. Die erwärmte Luft muss durch den Luftschacht an der Rückwand des Möbels nach oben abziehen können. Die Lüftungsquerschnitte sollen mindestens 200 cm² betragen.



Achtung! Um die Funktion des Gerätes nicht zu beeinträchtigen, dürfen diese Lüftungsöffnungen nicht abgedeckt oder zugestellt werden.

Einbau

Maßzeichnung



Siehe beiliegende Montageanweisung.

Prüfen Sie bitte nach dem Einbau des Geräts, insbesondere nach Türanschlagwechsel, ob die Türdichtung ringsum richtig abdichtet. Eine undichte Türdichtung kann zu verstärkter Reifbildung und dadurch zu höherem Energieverbrauch führen (siehe auch Abschnitt „Abhilfe bei Störungen“).

Downloaded from Fridge-Manual.com Manuals

Elektrischer Anschluss

Für den elektrischen Anschluss ist eine vorschriftsmäßig installierte Schutzkontakt-Steckdose erforderlich. Sie sollte so gesetzt sein, dass ein Ziehen des Netzsteckers möglich ist.
Die zum Anschluss des Gerätes nötige Schutzkontakt-Steckdose muss oberhalb des Einbau-Schrankes sitzen.
Die elektrische Absicherung muss mindestens 10/16 Ampere betragen.
Ist die Steckdose bei eingebautem Gerät nicht mehr zugänglich, muss eine geeignete Maßnahme in der Elektroinstallation sicherstellen, dass das Gerät vom Netz getrennt werden kann (z. B. Sicherung, LS-Schalter, Fehlerstrom-Schutzschalter oder dergleichen mit einer Kontaktöffnungsweite von min. 3 mm).

☞ Vor Inbetriebnahme am Typschild des Gerätes überprüfen, ob Anschlußspannung und Stromart mit den Werten des Stromnetzes am Aufstellort übereinstimmen.

Z. B.: AC 220 ... 240 V 50 Hz oder
220 ... 240 V ~ 50 Hz

(d. h. 220 bis 240 Volt Wechselstrom, 50 Hertz)
Das Typschild befindet sich links im Innenraum des Gerätes.

Downloaded from Fridge-Manual.com Manuals

Gerätebeschreibung

Geräteansicht



1 = Bedienblende
2 = Butter-/Käsefach mit Klappe
3 = Türabstellfach
4 = Flaschenfach
5 = LONGFRESH 0°C Kaltraum
6 = Abstellfläche (nutzbar für Dosen und Flaschen)
7 = Abstellfläche
8 = Luftfilter
9 = Typschild
10 = Türkontakt (für Beleuchtung und Alarm)

Downloaded from Fridge-Manual.com Manuals

Bedienblende



1 Betriebskontrollanzeige (grün)
2 Taste EIN/AUS
3 Taste zur Temperatureinstellung (für wärmere Temperaturen)
4 Temperaturanzeige
5 Taste zur Temperatureinstellung (für kältere Temperaturen)
6 Anzeige für eingeschaltete TURBO COOLMATIC-Funktion (gelb)
• TURBO COOLMATIC für Intensivkühlen im Kühlraum
7 Taste TURBO COOLMATIC

Tasten zur Temperatureinstellung

Die Temperatureinstellung erfolgt durch die Tasten "+" (WÄRMER) und "-" (KÄLTER).

Die Tasten stehen in Verbindung mit der Temperaturanzeige.

- Durch Druck auf eine der beiden Tasten WÄRMER oder KÄLTER wird die Temperaturanzeige von der IST-Temperatur (Temperaturanzeige leuchtet) auf die SOLL-Temperatur (Temperaturanzeige blinkt) umgeschaltet.
- Mit jedem weiteren Druck auf eine der beiden Tasten wird die SOLL-Temperatur um 1°C weiter gestellt.
- Wird keine Taste gedrückt, schaltet die Temperaturanzeige nach kurzer Zeit (ca. 5 sec.) automatisch wieder auf die IST-Temperatur zurück.

SOLL-Temperatur bedeutet:
Die Temperatur, die im Kühlraum vorhanden sein soll. Die SOLL-Temperatur wird durch blinkende Zahlen angezeigt.

IST-Temperatur bedeutet:
Die Temperaturanzeige zeigt die Temperatur an, die momentan tatsächlich im Kühlraum vorhanden ist. Die IST-Temperatur wird durch leuchtende Zahlen angezeigt.

Downloaded from Fridge-Manual.com Manuals

Temperaturanzeige

Die Temperaturanzeige kann mehrere Informationen anzeigen.

- Bei normalem Betrieb wird die Temperatur angezeigt, die momentan im Kühlraum vorhanden ist (IST-Temperatur).
- Während der Temperatureinstellung wird blinkend die im Moment eingestellte Kühlraumtemperatur angezeigt (SOLL-Temperatur).
- Erkennt die Elektronik des Gerätes einen technischen Defekt wird statt der Temperatur ein Quadrat angezeigt.
  Das Gerät arbeitet in einem Notprogramm bis der Kundendienst die Reparatur durchgeführt hat.

  Achtung: Es ist normal, dass die Temperaturanzeige die tatsächliche Temperatur etwas zeitverzögert anzeigt.

Luftfilter

In der Rückwand des Kühlraumes befindet sich ein Aktivkohlefilter („AIR FILTER“).
Durch den Filter wird im Kühl- und im LONGFRESH 0°C Kaltraum durch Bindung unangenehmer Gerüche die Luft gereinigt und damit die Lagerqualität zusätzlich verbessert.

Hinweis: Der Aktivkohlefilter ist ein Verschleißteil und fällt nicht unter die Garantieleistungen.

Downloaded from Fridge-Manual.com Manuals

Einsetzen des Aktivkohlefilters

Bei Lieferung des Kühlschranks ist der Kohlefilter in einer Schutzfolie verpackt, um eine lange Lebensdauer zu gewährleisten. Vor Inbetriebnahme des Gerätes muss der Aktivkohlefilter in die Klappe an der Rückwand eingesetzt werden.

☞ **1.** Klappe durch vorsichtiges Ziehen an der Oberkante öffnen (1).



2. Den Aktivkohlefilter aus der Verpackung nehmen und in die Führungen in der Klappe einsetzen (2).

3. Klappe wieder zudrücken.



Achtung!
Die Klappe während des Betriebes immer geschlossen halten!
Vorsicht beim Hantieren mit dem Filter, um Ablösung von Kohleteilen zu vermeiden.

Wechsel des Aktivkohlefilters

Zur Erhaltung der vollen Funktionsfähigkeit unter üblichen Betriebsbedingungen ist der Aktivkohlefilter einmal pro Jahr auszutauschen. Einen passender Aktivkohlefilter erhaltern Sie über Ihren Fachhändler oder den Kundendienst.

☞ **1.** Klappe durch vorsichtiges Ziehen an der Oberkante öffnen (1).



2. Den verbrauchten Aktivkohlefilter aus den Führungen herausziehen (2).

3. Den neuen Aktivkohlefilter aus der Verpackung nehmen und in die Führungen in der Klappe einsetzen (2). Klappe wieder zudrücken.



Downloaded from Fridge-Manual.com Manuals

Vor Inbetriebnahme

☞ Das Geräteinnere und alle Ausstattungsteile bitte vor Erstinbetriebnahme reinigen (siehe Abschnitt "Reinigung und Pflege").

Wartezeit

Zur wartungsfreien Dauerschmierung befindet sich in der Kapsel des Motorkompressors Öl. Durch Schräglage beim Transport kann dieses Öl in das geschlossene Rohrsystem gelangen. Es läuft selbst wieder in die Kapsel zurück, wenn mit dem Einschalten des Gerätes ca.1 Stunde gewartet wird.

Inbetriebnahme – Temperatur einstellen

☞ **1.** Netzstecker in die Steckdose stecken.

2. Taste KÜHLEN EIN/AUS drücken.
Die grüne Betriebskontrollanzeige leuchtet.

3. Auf eine der Tasten "+" (WÄRMER) oder "-" (KÄLTER) drücken.
Die Temperaturanzeige schaltet um und zeigt blinkend die momentan eingestellte SOLL-Temperatur an.

4. Gewünschte Temperatur durch Drücken der Tasten WÄRMER und KÄLTER einstellen (siehe Abschnitt "Tasten zur Temperatureinstellung").
Die Temperaturanzeige zeigt sofort die geänderte Einstellung an.
Mit jedem Tastendruck wird die Temperatur um 1°C weitergestellt.

Einstellbarer Temperaturbereich: +3°C bis +8°C.

ⓘ Aus ernährungswissenschaftlicher Sicht ist +5 °C für den Kühlraum als ausreichend kalte Lagertemperatur anzusehen.

5. Wenn nach erfolgter Temperatureinstellung die Tasten nicht mehr gedrückt werden, schaltet die Temperaturanzeige nach kurzer Zeit (ca. 5 sec.) um und zeigt wieder die momentan im Kühlraum vorhandene IST-Temperatur an. Die Anzeige wechselt von blinkenden zu leuchtenden Ziffern.

Der Kompressor startet und läuft dann automatisch.

Hinweis: Bei Änderung der Einstellung läuft der Kompressor nicht sofort an, wenn gerade automatisch abgetaut wird.

ⓘ Da die Lagertemperatur im Kühlraum schnell erreicht wird, können Sie gleich nach dem Einschalten Kühlgut einlagern.

Downloaded from Fridge-Manual.com Manuals

Im LONGFRESH 0°C Kaltraum wird die Temperatur automatisch geregelt. Sie bleibt konstant nahe 0°C, eine Einstellung ist nicht erforderlich.

Hinweis: Ihr Gerät ist mit einer dynamischen Umluftkühlung ausgestattet. Für eine optimale Anpassung an die erforderliche Kühlleistung im Kühlabteil und im LONGFRESH 0°C Kaltraum wird der Ventilator in verschiedenen Leistungsstufen betrieben. Daraus ergeben sich unterschiedlich wahrnehmbare Ventilatorgeräusche in Bezug auf Einschaltdauer und Drehzahl. Dies ist normal und stellt keine Unregelmäßigkeit oder Defekt dar.

TURBO COOLMATIC

TURBO COOLMATIC-Taste

Die TURBO COOLMATIC-Funktion eignet sich zum schnellen Abkühlen größerer Kühlgutmengen im Kühlraum, z. B. Getränke, Salate anläßlich einer Party.

1. Durch Drücken der Taste TURBO COOLMATIC wird die TURBO COOLMATIC-Funktion eingeschaltet. Die gelbe Anzeige leuchtet.
   Die TURBO COOLMATIC-Funktion sorgt jetzt für intensives Kühlen. Dabei wird automatisch eine SOLL-Temperatur von +3°C vorgegeben. Nach Ablauf von 6 Stunden wird die TURBO COOLMATIC-Funktion selbsttätig beendet. Die ursprünglich eingestellte SOLL-Temperatur ist dann wieder maßgebend und die Temperaturanzeige zeigt die momentane Kühlraumtemperatur.
2. Durch erneutes Drücken der Taste TURBO COOLMATIC kann die TURBO COOLMATIC-Funktion jederzeit manuell beendet werden. Die gelbe Anzeige erlischt.

Downloaded from Fridge-Manual.com Manuals

Gerät abschalten

Zum Schutz des Kühlgutes ist das Gerät gegen versehentliches Abschalten gesichert.

☞ Zum Abschalten die Taste EIN/AUS ca. 5 Sekunden gedrückt halten. In der Temperaturanzeige erfolgt ein sogenannter "Count down", dabei wird rückwärts von "3" nach "1" gezählt. Nach Erreichen der "1" schaltet das Gerät ab. Die Anzeigen erlöschen.

Hinweis: Die Einstellung des Geräts kann bei gezogenem Netzstecker oder fehlender Stromversorgung nicht geändert werden. Nach Anschluss an das Stromnetz nimmt das Gerät wieder den Zustand an, den es bei Netzunterbrechung hatte.

Soll das Gerät für längere Zeit außer Betrieb genommen werden:

☞ **1.** Gerät abschalten, dazu die Taste EIN/AUS drücken, bis die Anzeigen erlöschen (siehe oben).

2. Netzstecker ziehen oder Sicherung abschalten bzw. herausdrehen.

3. Gerät gründlich reinigen (siehe Abschnitt "Reinigung und Pflege").

4. Tür anschließend geöffnet lassen, um Geruchsbildung zu vermeiden.

Innenausstattung

Abstellflächen

Auf der Abstellfläche über dem LONGFRESH 0°C Kaltraum können Sie Dosen und Flaschen bequem liegend lagern. Die Struktur der Fläche verhindert hierbei ein seitliches Wegrollen der Flaschen.

Die übrigen Abstellflächen sind höhenverstellbar:

☞ **1.** Dazu die Abstellfläche soweit nach vorne ziehen, bis sie sich nach oben oder unten abschwenken und herausnehmen läßt.

2. Das Einsetzen in eine andere Höhe bitte in umgekehrter Reihenfolge vornehmen.



Downloaded from Fridge-Manual.com Manuals

Hohes Kühlgut einstellen:

☞ Die vordere Hälfte der zweiteiligen Glasabstellfläche herausnehmen und in eine andere Ebene einschieben. Dadurch gewinnen Sie Raum, um auf der darunterliegenden Abstellfläche hohes Kühlgut abzustellen.



Variable Innentür

Je nach Erfordernis kann das Türabstellfach nach oben herausgenommen und in andere Aufnahmen umgesetzt werden.

Flaschenhalter

Im Flaschenfach ist ein Flaschenhalter eingesetzt. Er dient als Kippschutz für einzelne Flaschen und ist seitlich verschiebbar.



LONGFRESH 0°C Kaltraum

Im LONGFRESH 0°C Kaltraum wird die Temperatur automatisch geregelt. Sie bleibt konstant nahe 0°C, eine Einstellung ist nicht erforderlich.

Die Lagertemperatur konstant nahe 0°C und die relative Luftfeuchtigkeit zwischen 45 und 90 % ermöglichen für die verschiedenen Lebensmittel optimale Bedingungen.

ⓘ Im LONGFRESH 0°C Kaltraum können deshalb verschiedene frische Lebensmittel bis zu 3 mal länger bei besserer Qualität im Vergleich zur Lagerung im normalen Kühlfach gelagert werden.
Dadurch erweitert sich Ihre Vorratshaltung für frische Lebensmittel. Geschmack, Frischegrad, Genuss- und Nährwerte (Vitamine und Mineralstoffe) bleiben in hohem Maße erhalten. Ein Gewichtsverlust

Downloaded from Fridge-Manual.com Manuals

von Gemüse und Obst verringert sich. Die Ernährung kann ernährungsphysiologisch hochwertiger erfolgen.

Das LONGFRESH 0°C Kaltraum ist auch für das langsame Auftauen von Lebensmitteln geeignet. In diesem Fall sind die aufgetauten Lebensmittel bis zu zwei Tage im LONGFRESH 0°C Kaltraum haltbar.

Feuchte einstellen



Die beiden Schubladen können entsprechend den gewünschten Lagerbedingungen jede unabhängig von einander mit niedrigerer oder höherer Luftfeuchtigkeit genutzt werden.
Die Einstellung erfolgt für jede Schublade getrennt durch Betätigung der Schieber in der Schubladenfront.

- **„Trocken"**: niedrige relative Luftfeuchtigkeit von weinger als 50%

  Eine niedrige relative Luftfeuchtigkeit wird erreicht wenn beide Schieber in die Position geschoben werden und die Luftschlitze vollständig geöffnet sind.

- **„Feucht"**: hohe relative Luftfeuchtigkeit von bis zu 90%

  Eine relative Luftfeuchtigkeit von bis zu 90% wird abhängig von der Beladung erreicht wenn beide Schieber in die Position geschoben werden und die Luftschlitze vollständig geschlossen sind.

Schubladen

Die Gitterfächer im Inneren der Schublade sorgen für eine einwandfreie Lüftung. Diese werden für eine optimale Erhaltung der Lebensmittel sorgen.



Downloaded from Fridge-Manual.com Manuals

Die stabilen Kälteschubladen sind kippgesichert und in Endstellung arretiert.
Zum Herausnehmen ziehen Sie die Schubladen bis zur Arretierung heraus, kippen sie nach oben und ziehen sie nach vorn heraus.

Richtig lagern

Der Kühlraum ist mit einem Ventilator ausgestattet, der ein schnelles Abkühlen der Nahrungsmittel und eine gleichmäßige Temperaturverteilung sowohl im Kühlraum als auch im 0°C LONGFRESH Kaltraum ermöglicht.

Im Kühlraum lagern Sie beispielweise
- Getränke, Konserven, Dosen, Flaschen;
- Backwaren, fertige Speisen;
- für den kurzfristigen Verbrauch bestimmten Waren;
- die für den LONGFRESH 0°C Kaltraum nicht geeigneten kälteempfindlichen Lebensmittel.

Tipps:

- Keine warmen Speisen oder offenen Flüssigkeiten in den Kühlschrank stellen.
- Lebensmittel so einlagern, dass die Luft frei zirkulieren kann.
- Butter und für den Verzehr bestimmten Käse im Butter-/Käsefach aufbewahren, dies bewahrt die Streichfähigkeit und das Aroma.
- Lebensmittel, insbesondere grünen Salat immer abgedeckt oder verpackt lagern um Austrocknung und Geruchs- oder Geschmacksübertragung auf anderes Kühlgut zu vermeiden.

  Zum Verpacken eignen sich:
  – Frischhaltebeutel und -folien aus Polyäthylen;
  – Kunststoffbehälter mit Deckel;
  – Spezielle Hauben aus Kunststoff mit Gummizug;
  – Aluminiumfolie.
- Hochprozentigen Alkohol nur dicht verschlossen und stehend lagern.
- Lagern Sie keine Behälter mit brennbaren oder explosiven Stoffen im Kühlschrank.

Im LONGFRESH 0°C Kaltraum lagern Sie alle hierfür geeigneten Lebensmittel.

Downloaded from Fridge-Manual.com Manuals

Richtwerte für die Lagerdauer für frische Lebensmittel

Lebensmittel	Bei Lagerung	Lagerdauer
Zwiebeln	"trocken"	bis 5 Monate
Butter	"trocken"	bis 1 Monat
Schweinefleisch in größeren Portionen	"trocken"	bis 10 Tage
Rindfleisch, Wild, Schweinefleisch kleingeschnitten, Geflügel	"trocken"	bis 7 Tage
Tomatensauce	"trocken"	bis 4 Tage
Fisch, Schalentiere, Krustentiere, Gekochte Fleischprodukte	"trocken"	bis 3 Tage
Gekochte Fischprodukte	"trocken"	bis 2 Tage
Salate, Gemüse Karotten, Küchenkräuter, Rosenkohl, Sellerie	"feucht"	bis 1 Monat
Artischocken, Blumenkohl, Chicoree, Eisbergsalat, Endiviensalat, Feldsalat, Kopfsalat, Lauch, Radicchiosalat	"feucht"	bis 21 Tage
Brokkoli, Chinakohl, Grünkohl, Kohlkopf, Radieschen, Wirsing	"feucht"	bis 14 Tage
Erbsen, Kohlrabi	"feucht"	bis 10 Tage
Lauchzwiebeln, Rettich, Spargel, Spinat	"feucht"	bis 7 Tage

Downloaded from Fridge-Manual.com Manuals

Lebensmittel	Bei Lagerung	Lagerdauer
Obst (*) Birnen, Datteln (frisch), Erdbeeren, Pfirsiche (*)	“feucht”	bis 1 Monat
Äpfel (kälteunempfindlich), Quitten	“feucht”	bis 20 Tage
Pflaumen (*), Rhabarber, Stachelbeeren	“feucht”	bis 21 Tage
Aprikosen, Kirschen	“feucht”	bis 14 Tage
Zwetschgen, Trauben	“feucht”	bis 10 Tage
Brombeeren, Johannisbeeren	“feucht”	bis 8 Tage
Feigen (frisch)	“feucht”	bis 7 Tage
Heidelbeeren, Himbeeren	“feucht”	bis 5 Tage

Torten mit Sahne und andere Konditoreiprodukte lassen sich im LONGFRESH 0°C Kaltraum optimal 2 oder 3 Tage aufbewahren.

Nicht in das LONGFRESH 0°C Kaltraum gehören:

- kälteempfindliche Südfrüchte und Obst, die bei Keller- oder Raumtemperatur gelagert werden, wie Ananas, Bananen, Grapefruit, Melonen, Mango, Papaya, Orangen, Zitronen, Kiwi.
- Die nicht oben genannten Lebensmittel sind im normalen Kühlfach aufzubewahren (z.B. alle Sorten Käse, Aufschnitte, usw.).

Eine hohe Luftfeuchtigkeit in den Schubladen ist abhängig von dem Feuchtegehalt der eingelegten Lebensmittel wie Salat, Gemüse oder Obst und von der Häufigkeit des Türöffnens.

Das LONGFRESH 0°C Kaltraum ist auch für das langsame Auftauen von Lebensmitteln geeignet. In diesem Fall sind die aufgetauten Lebensmittel bis zu zwei Tage im LONGFRESH 0°C Kaltraum haltbar.

(*) Je reifer die Früchten sind, desto kürzer ist ihre Haltbarkeit.

Downloaded from Fridge-Manual.com Manuals

Tipps:

- Achten Sie beim Einkaufen auf die Frische der Lebensmittel. Qualität und Frischegrad sind entscheidend für die Lagerdauer.
- Tierische Lebensmittel immer verpackt und trocken lagern.
- Beachten Sie, dass eiweißreichere Lebensmittel schneller verderben. So verderben z.B. Schalen- und Krustentiere schneller als Fisch und Fisch wiederum schneller als Fleisch. Durch Lagerung im 0°C Fach kann auch bei diesen Lebensmitteln die Lagerdauer ohne qualitative Einbußen bis zum 3-fachen verlängert werden.
- Alle Lebensmittel, die in den 0 °C-Fächern gelagert werden, sollten ca. 15-30 Minuten vor dem Verzehr aus den Schubladen genommen werden, vor allem Obst und Gemüse, das ohne weiteren Garprozess verzehrt wird. Bei Raumtemperatur entfalten sich Aroma und Geschmack, und der Genusswert erhöht sich.

Abtauen

Der Kühlraum taut automatisch ab

Das Abtauen des Kühlraums erfolgt automatisch.

Reinigung und Pflege

Aus hygienischen Gründen sollte das Geräteinnere, einschließlich Innenausstattung, regelmäßig gereinigt werden.

⚠ **Warnung!**

- Das Gerät darf während der Reinigung nicht am Stromnetz angeschlossen sein. Stromschlaggefahr! Vor Reinigungsarbeiten Gerät abschalten und Netzstecker ziehen oder Sicherung abschalten bzw. herausdrehen.
- Das Gerät nie mit Dampfreinigungsgeräten reinigen. Feuchtigkeit könnte in elektrische Bauteile gelangen, Stromschlaggefahr! Heißer Dampf kann zu Schäden an Kunststoffteilen führen.
- Das Gerät muss trocken sein, bevor Sie es wieder in Betrieb nehmen.

Achtung!

- Ätherische Öle und organische Lösungsmittel können Kunststoffteile angreifen, z. B.
  - Saft von Zitronen- oder Apfelsinenschalen;
  - Reinigungsmittel, die Essigsäure enthalten.

Downloaded from Fridge-Manual.com Manuals

Solche Substanzen nicht mit den Geräteteilen in Kontakt bringen.

- Keine scheuernden Reinigungsmittel verwenden.

☞1. Kühlgut herausnehmen und abgedeckt an einem kühlen Ort lagern.

2. Gerät abschalten und den Netzstecker ziehen oder Sicherung abschalten bzw. herausdrehen.
3. Entfernen Sie Reif mit einem weichen Kunststoffschaber, z. B. Teigkratzer. Keinesfalls harte oder spitze Gegenstände dazu benutzen.
4. Gerät einschließlich Innenausstattung mit einem Lappen und lauwarmem Wasser reinigen. Eventuell etwas handelsübliches Geschirrspülmittel beigeben.
5. Anschließend mit klarem Wasser nachwischen und trockenreiben.
6. Nachdem alles trocken ist, Lebensmittel wieder einlagern und Gerät wieder in Betrieb nehmen.

Die untere Abstellfläche, die das Kühlabteil vom 0°C-Fach trennt, kann zur Reinigung entnommen werden. Hierzu die Platte gerade herausziehen.

Die Abdeckungen über den Schubladen können zum Reinigen entnommen werden. Zur Sicherstellung der Funktion im 0°C-Kaltraum müssen diese nach der Reinigung unbedingt wieder an ihrem Platz eingelegt werden.

Tipps zur Energie-Einsparung

- Das Gerät nicht in der Nähe von Herden, Heizkörpern oder anderen Wärmequellen aufstellen. Bei hoher Umgebungstemperatur läuft der Kompressor häufiger und länger.
- Ausreichende Be- und Entlüftung des Gerätes gewährleisten. Lüftungsöffnungen niemals abdecken.
- Keine warmen Speisen in das Gerät stellen. Warme Speisen erst abkühlen lassen.
- Tür nur so lange wie nötig geöffnet lassen.
- Die Temperatur nicht kälter als nötig einstellen.

Downloaded from Fridge-Manual.com Manuals

Was tun, wenn ...

Abhilfe bei Störungen

Möglicherweise handelt es sich bei einer Störung nur um einen kleinen Fehler, den Sie anhand nachfolgender Hinweise selbst beheben können. Führen Sie keine weiteren Arbeiten selbst aus, wenn nachstehende Informationen im konkreten Fall nicht weiterhelfen.

Warnung! Reparaturen am Kältegerät dürfen nur von Fachkräften durchgeführt werden. Durch unsachgemäße Reparaturen können erhebliche Gefahren für den Benutzer entstehen. Wenden Sie sich im Reparaturfall an Ihren Fachhändler oder an unseren Kundendienst.

Störung	Mögliche Ursache	Abhilfe
Gerät arbeitet nicht.	Gerät ist nicht eingeschaltet.	Gerät einschalten.
	Netzstecker ist nicht eingesteckt oder lose.	Netzstecker einstecken.
	Sicherung hat ausgelöst oder ist defekt.	Sicherung überprüfen, gegebenenfalls erneuern.
	Steckdose ist defekt.	Störungen am Stromnetz behebt Ihr Elektrofachmann.
Gerät kühlt zu stark.	Temperatur ist zu kalt eingestellt.	Wärmere Temperatureinstellung wählen.
Die Kühlraumtemperatur ist nicht ausreichend.	Temperatur ist nicht richtig eingestellt.	Bitte im Abschnitt "Inbetriebnahme" nachsehen.
	Tür war längere Zeit geöffnet.	Tür nur so lange wie nötig geöffnet lassen.
	Innerhalb der letzen 24 Std. wurden größere Mengen warmer Lebensmittel eingelagert.	Kältere Temperatureinstellung wählen.
	Das Gerät steht neben einer Wärmequelle.	Bitte im Abschnitt "Aufstellort" nachsehen.
Innenbeleuchtung funktioniert nicht.	Lampe ist defekt.	Bitte im Abschnitt "Lampe auswechseln" nachsehen.

Downloaded from Fridge-Manual.com Manuals

Störung	Mögliche Ursache	Abhilfe
Nach Drücken der Taste TURBO COOLMATIC oder nach Änderung der Temperatureinstellung läuft der Kompressor nicht sofort an.	Dies ist normal, es liegt keine Störung vor.	Der Kompressor läuft nach einiger Zeit selbsttätig an.

Lampe auswechseln

Warnung! Stromschlaggefahr! Vor dem Lampenwechsel Gerät abschalten und den Netzstecker ziehen oder Sicherung abschalten bzw. herausdrehen.

Lampendaten: 220-240 V, max. 25 W, Fassung: E 14

1. Zum Abschalten des Gerätes die Taste EIN/AUS drücken, bis die Betriebskontrollanzeige erlischt.
2. Netzstecker ziehen.
3. Zum Auswechseln der Lampe Verschluss drücken und gleichzeitig die Lampenabdeckung in Pfeilrichtung herausnehmen.
4. Defekte Lampe auswechseln.
5. Lampenabdeckung wieder einsetzen.
6. Gerät wieder in Betrieb nehmen.



Downloaded from Fridge-Manual.com Manuals

Betriebsgeräusche

Folgende Geräusche sind charakterstisch für Kältegeräte:

- **Klicken**
  Immer wenn der Kompressor ein- oder ausschaltet, ist ein Klicken zu hören.
- **Summen**
  Sobald der Kompressor arbeitet, können Sie ihn summen hören.
- **Blubbern/Plätschern**
  Wenn Kältemittel in dünne Rohre einströmt, können Sie ein blubberndes oder plätscherndes Geräusch hören. Auch nach dem Abschalten des Kompressors ist dieses Geräusch noch kurze Zeit hörbar.
- **Rauschen**
  Ihr Gerät ist mit einer dynamischen Umluftkühlung ausgestattet. Für eine optimale Anpassung an die erforderliche Kühlleistung im Kühlraum und im LONGFRESH 0° C Kaltraum wird der Ventilator in verschiedenen Leistungsstufen betrieben. Daraus ergibt sich ein unterschiedlich wahrnehmbares Ventilatorgeräusch in Bezug auf Einschaltdauer und Drehzahl. Dies ist normal und stellt keine Unregelmäßigkeit oder Defekt dar.

Bestimmungen, Normen, Richtlinien

Das Kältegerät ist für den Haushalt bestimmt und wurde unter Beachtung der für diese Geräte geltenden Normen hergestellt.
Bei der Fertigung wurden insbesondere die nach dem Gerätesicherheitsgesetz (GSG), der Unfallverhütungsvorschrift für Kälteanlagen (VBG 20) und den Bestimmungen des Verbandes Deutscher Elektrotechniker (VDE) notwendigen Maßnahmen getroffen.
Der Kältekreislauf wurde auf Dichtheit geprüft.

CE Dieses Gerät entspricht den folgenden EG-Richtlinien:

- 73/23/EWG vom 19.2.1973 - Niederspannungsrichtlinie
- 89/336/EWG vom 3.5.1989
  (einschließlich Änderungsrichtlinie 92/31/EWG) - EMV-Richtlinie
- 94/2/EG vom 21. 01. 1994 - Richtlinie zur Energieettikettierung
- 96/57 EG vom 3. 9. 1996 - Anforderung im Hinblick auf die Energieeffizienz von elektrischen Haushaltskühl- und Gefriergeräten und entsprechenden Kombinationen.

Downloaded from Fridge-Manual.com Manuals

Fachbegriffe

- **Kältemittel**
  Flüssigkeiten, die zur Kälteerzeugung verwendet werden können, nennt man Kältemittel. Sie haben einen verhältnismäßig niedrigen Siedepunkt, so niedrig, dass die Wärme der im Kältegerät lagernden Lebensmittel das Kältemittel zum Sieden bzw. Verdampfen bringen kann.
- **Kältemittelkreislauf**
  Geschlossenes Kreislaufsystem, in dem sich das Kältemittel befindet. Der Kältemittelkreislauf besteht im wesentlichen aus Verdampfer, Kompressor, Verflüssiger sowie aus Rohrleitungen.
- **Verdampfer**
  Im Verdampfer verdampft das Kältemittel. Wie alle Flüssigkeiten benötigt Kältemittel zum Verdampfen Wärme. Diese Wärme wird dem Geräteinnenraum entzogen, der dadurch abkühlt. Deshalb ist der Verdampfer im Geräteinnenraum angeordnet oder unmittelbar hinter der Innenwand eingeschäumt und dadurch nicht sichtbar.
- **Kompressor**
  Der Kompressor sieht aus wie eine kleine Tonne. Er wird von einem eingebauten Elektromotor angetrieben und ist hinten im Sockelbereich des Gerätes untergebracht. Aufgabe des Kompressors ist es, dampfförmiges Kältemittel aus dem Verdampfer abzuziehen, zu verdichten und zum Verflüssiger weiterzuleiten.
- **Verflüssiger**
  Der Verflüssiger hat meist die Form eines Gitters. Im Verflüssiger wird das vom Kompressor verdichtete Kältemittel verflüssigt. Dabei wird Wärme frei, die über die Oberfläche des Verflüssigers an die Umgebungsluft abgegeben wird. Der Verflüssiger ist deshalb außen, meist an der Geräterückseite angebracht.

Für Deutschland: Sie können Ersatzteile, Zubehör und Pflegemittel online bestellen unter **http://www.aeg-hausgeraete.de**

Für Österreich: Sie können Ersatzteile, Zubehör und Pflegemittel für Ihr AEG Gerät über das Internet bestellen.
Ersatzteile Online finden Sie auf unsere Homepage:
http://www.aeg-hausgeraete.at unter der Rubrik "Service".

Downloaded from Fridge-Manual.com Manuals

Dear customer,

Before placing your new refrigerator/freezer into operation please read these operating instructions carefully. They contain important information for safe use, for installation and for care of the appliance.

Please keep these operating instructions for future reference. Pass them on to possible new owners of the appliance.

These operating instructions are for use with several technically comparable models with varying accessories. Please observe the notes which apply to your model.

Notes which are important for your safety or for the proper functioning of the appliance are stressed with a warning triangle and/ or with signal words (**Warning!, Caution!, Important!**). Please observe the following carefully.

1. This symbol guides you step by step in the operation of the appliance.

2. ....

Supplementary information regarding operation and practical applications of the appliance appear after this symbol.

Tips and notes concerning economical and environmentally sound use of the appliance are marked with the cloverleaf.

Explanations of the technical terminology used in the operating instructions can be found at the end in the section "Technical Terminology".

The operating instructions contain instructions for the correction of possible malfunctions by the user in the section "What to do if ...". If these instructions should not be sufficient, please contact your local Customer Care Department.

Printed on paper manufactured with environmentally sound processes
he who thinks ecologically acts accordingly...

Downloaded from Fridge-Manual.com Manuals

Contents

Safety 31
Disposal 33
Appliance Packaging Information 33
Disposal of old Appliances 33
Remove transport packaging 34
Installation 34
Installation Location 34
Your refrigerator needs ventilation 35
Installation 35
Electrical connection 36
Description of the appliance 37
View of the appliance 37
Control panel / Temperature setting buttons 38
Temperature display / Air Filter 39
Prior to Initial Start–Up 41
Starting up and temperature regulation 41
TURBO COOLMATIC 42
TURBO COOLMATIC-Button 42
Switching off the appliance 42
Interior Accessories 43
Storage shelves 43
Variable Inner Door / Bottle Holder 44
LONGFRESH 0°C compartment 44
Humidity control 45
Drawers 45
Correct Storage 46
Defrosting 49
The fridge defrosts automatically 49
Cleaning and Care 49
Energy Saving Tips 50
What to do if 50
Correcting Malfunctions 50
Changing the light bulb 52
Customer Service 52
Noises during Operation 53
Regulations, Standards, Guidelines 53
Technical terminology 54

Downloaded from Fridge-Manual.com Manuals

Safety

The safety aspects of our refrigerators comply with accepted technical standards and the German Appliance Safety Law. Nevertheless, we consider it our obligation to make you aware of the following safety information:

Intended use

- The refrigerator is intended for use in the home. It is suitable for the storing of food at low temperature. If the appliance is used for purposes other than those intended or used incorrectly, no liability can be accepted by the manufacturer for any damage that may be caused.
- Alterations or changes to the refrigerator are not permitted for reasons of safety.
- If you use the refrigerator in a commercial application or for purposes other than the cooling of foods, the manufacturer accepts no liability for any damages which may occur.

Prior to initial start–up

- Check the appliance for transport damage. Under no circumstance should a damaged appliance be plugged in. In the event of damage, please contact your supplier.
- Ensure that the appliance does not stand on the electrical supply cable. **Important:** if the supply cable is damaged, it must be replaced by a special cord or assembly available from the manufacturer or its Customer Service.

Refrigerant

The refrigerant isobutane (R600a) is contained within the refrigerant circuit of the appliance, a natural gas with a high level of environmental compatibility, which is nevertheless flammable.

- **Warning** - During transportation and installation of the appliance, be certain that none of the components of the refrigerant circuit become damaged.
- If the refrigerant circuit should become damaged:

– avoid open flames and sources of ignition;
– thoroughly ventilate the room in which the appliance is situated.

Safety of children

- Packaging (e.g. wraps, polystyrene) can be dangerous for children. There is a risk of suffocation! Keep packaging material away from children!

Downloaded from Fridge-Manual.com Manuals

- Please make old appliances unusable prior to disposal. Pull out the mains plug, cut off the mains cable, break or remove spring or bolt catches, if fitted. By doing this you ensure that children cannot lock themselves in the appliance when playing (there is risk of suffocation!) or get themselves into other dangerous situations.
- Often children cannot recognise the hazards present in household appliances. It is therefore important that you ensure adequate supervision and never let children play with the appliance!

Daily Operation

- Containers with flammable gases or liquids can leak at low temperatures. There is a risk of an explosion! Do not store any containers with flammable materials such as spray cans, fire extinguisher refill cartridges etc in the refrigerator and/or freezer.
- **Warning** - Do not operate any electrical appliances in the refrigerator and/or freezer (e.g. electric ice cream makers, mixers etc.).
- **Warning** - In order not to impair the function of the appliance, never cover or obstruct the ventilation openings.
- **Warning** - Do not damage the cooling circuit.
- Before cleaning the appliance, always switch off the appliance and unplug it, or pull the house fuse or switch off the circuit breaker.
- When unplugging always pull the plug from the mains socket, do not pull on the cable.

In case of malfunction

- If a malfunction occurs on the appliance, please look first in the "What to do if ..." section of these instructions. If the information given there does not help, please do not perform any further repairs yourself.
- Refrigerators/freezers may only be repaired by qualified service engineers. Improper repairs can give rise to significant hazards. If your appliance needs repairing, please contact your specialist dealer or our Customer Service.

Downloaded from Fridge-Manual.com Manuals

Disposal

Appliance Packaging Information

All materials are environmentally sound! They can be disposed of or burned at an incinerating plant without danger.

About the materials: The plastics can be recycled and are identified as follows:

>PE< for polyethylene, e.g. the outer covering and the bags in the interior.

>PS< for polystyrene foam, e.g. the pads, which are all free of chlorofluorocarbon.

The carton parts are made from recycled paper and should be disposed of at a waste-paper recycling collection location.

Disposal of old Appliances

For environmental reasons, refrigeration appliances must be disposed of properly. This applies to your old appliance, and - at the end of its service life - for your new appliance as well.

Warning! Before disposing of old appliances make them inoperable. Remove plug from mains, sever the power cable, remove or destroy any snap or latch closures. This ensures that playing children do not lock themselves inside the appliance (danger of suffocation!) or place themselves into other life-endangering situations.

Disposal:

- The appliance may not be disposed of with domestic waste or bulky refuse.
- The refrigerant circuit, especially the heat exchanger at the back of the appliance, must not be damaged.
- The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it shall be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Downloaded from Fridge-Manual.com Manuals

Remove transport packaging

The appliance and the interior fittings are protected for transport.

☞ 1. Pull off the adhesive tape on the left and right side of the door.

2. Remove all adhesive tape and packing pieces from the interior of the appliance.

Installation

Installation Location

The appliance should be set up in a well ventilated, dry room.

Energy use and efficient performance of the appliance is affected by the ambient temperature.

The appliance should therefore
– not be exposed to direct sunlight;
– not be installed next to radiators, cookers or other sources of heat;
– only be installed at a location whose ambient temperature corresponds to the climate classification, for which the appliance is designed.

The climate classification can be found on the rating plate, which is located at the left on the inside of the appliance.

The following table shows which ambient temperature is correct for each climate classification:

Climate classification	for an ambient temperature of
SN	+10 to +32 °C
N	+16 to +32 °C
ST	+18 to +38 °C
T	+18 to +43 °C

Installation directly under a hob is not allowed. The temperatures of the hob, which in part are quite high, may damage the appliance.

If a hob is installed near the appliance, the corresponding installation and safety instructions must be adhered to. Considering the numerous installation conditions which are possible, there is no way of providing detailed information here.

It is necessary to avoid overheating of the appliance by maintaining

Downloaded from Fridge-Manual.com Manuals

adequate distances from heat sources and by the use of a suitable thermal insulation plate. Proper ventilation of the appliance must also be ensured.

Your refrigerator needs ventilation

Integratable models (i-appliances)



The integrated door of the furniture cabinet largely seals the installation recess. i-appliances must therefore be provided with ventilation by having an opening in the furniture plinth. The warmed air must be able to be exhausted upwards through the air shaft on the furniture back.
The ventilation cross-sections should be at least 200 cm².
Warning - To ensure the appliance functions correctly, never cover or obstruct the ventilation openings.

Installation

Dimensioned drawing



See installation instructions supplied.
Please check whether, after installing your appliance and especially after reversing the door, the door seal seals right round. A badly fitting door seal may lead to heavy frosting and thereby to a higher power consumption (see also „What to do if...“).

Downloaded from Fridge-Manual.com Manuals

Electrical connection

A correctly installed, earthed socket is required for the electrical supply. The supply must have a fuse rating of at least 10 Amps. If the socket is not accessible once the appliance is built in, the electrical installation must include suitable means of isolating the appliance from the mains (e.g. a fused spur).

☞ Before initial start-up, refer to the appliance rating plate to ascertain if supply voltage and current values correspond with those of the mains at the installation location.

e.g.: AC 220 ... 240 V 50 Hz or
220 ... 240 V ~50 Hz
(i.e. 220 to 240 volts alternating current, 50 Hertz)

The rating plate is inside the appliance on the left.

Downloaded from Fridge-Manual.com Manuals

Description of the appliance

View of the appliance



1 = Control panel
2 = Butter/cheese compartment with flap
3 = Door storage compartment
4 = Bottle holder
5 = LONGFRESH 0°C compartment with humidity control
6 = Storage shelf (suitable for cans and bottles)
7 = Storage shelves
8 = Air filter
9 = Rating plate
10 = Magnet holder for interior lighting and door alarm

Downloaded from Fridge-Manual.com Manuals

Control panel



1 Pilot light (green)
2 ON/OFF switch
3 Temperature setting buttons (for warmer temperatures)
4 Temperature display
5 Temperature setting buttons (for colder temperatures)
6 TURBO COOLMATIC indicator light (yellow)
• TURBO COOLMATIC for intensive fridge cooling
7 Push button for TURBO COOLMATIC

Temperature setting buttons

The temperature is adjusted using the „+“ (WARMER) and „-“ (COLDER) buttons.

These buttons are connected to the temperature display.

- The temperature display is switched over from the display of the ACTUAL temperature (temperature display is illuminated) to the display of the DESIRED temperature (temperature display flashes) by pressing one of the two buttons, „+“ or „-“.
- With each further press of one of the two buttons, the DESIRED temperature is adjusted by 1°C.
- If neither button is pressed, the temperature display automatically switches back after a short period (approx. 5 sec.) to the display of the ACTUAL temperature.

DESIRED temperature means:

The temperature that is required in the refrigerator, this can be adjusted to the temperatures shown in the display. The DESIRED temperature is indicated by flashing numbers.

ACTUAL temperature means:

The temperature display indicates the temperature that is currently

Downloaded from Fridge-Manual.com Manuals

present in the refrigerator. The ACTUAL temperature is indicated by continuously illuminated numbers.

Temperature Display

The temperature display can indicate several pieces of information.

- During normal operation, the temperature currently present in the refrigerator (ACTUAL temperature) is displayed.
- When the temperature is being adjusted, the temperature currently set flashes (DESIRED temperature).
- If the electronics in the appliance have detected a fault that prevents the ACTUAL temperature being measured, the temperature display shows a square. The appliance will continue to function using a backup programme until your local Customer Service engineer has repaired the appliance.

Air Filter

Your appliance is equipped with a charcoal filter "AIR FILTER" in the rear wall of the fridge compartment. The filter purifies the air from unwanted odours in the fridge and LONGFRESH compartment meaning that the storage quality will be further improved.

Note: Always keep the air ventilation flap closed.

The charcoal filter is a consumable accessory and as such is not covered by the guarantee.

Downloaded from Fridge-Manual.com Manuals

Installation of the charcoal filter

On delivery the charcoal filter is placed in a plastic bag to secure the length of life of the charcoal filter. The filter should be placed behind the flap before the appliance is turned on.

☞ **1.** Pull the cover outward (1).



2. The charcoal filter is then mounted in the slot found in the back of the cover (2).

3. Close the flap.



Important!
During operation, always keep the air ventilation flap closed.
The filter should be handled carefully so fragments do not loosen from the surface.

Changing the charcoal filter

To maintain the best performance the carbon filter should be changed every year.

New charcoal filters can be purchased from your local dealer.

☞ **1.** The filter is placed behind the cover and can be reached by pulling the cover outward (1).



2. The charcoal filter is then pulled out of its slot.

3. The new charcoal filter is placed in the existing slot (2). Close the flap.



Downloaded from Fridge-Manual.com Manuals

Prior to Initial Start–Up

☞ Please clean the appliance interior and all accessories prior to initial start-up (see section: “Cleaning and Care”).

Standby time

The oil for automatic lubrication contained in the compressor may flow into the refrigeration circuit if the appliance is transported in an inclined position. To allow the oil to flow back into the compressor, wait approximately 1 hour before placing the appliance in operation.

Starting up and temperature regulation

☞ **1.** Insert the plug into the plug socket. When the refrigerator compartment door is opened, the internal lighting is switched on.

2. Press ON/OFF button.
The green mains pilot indicator and the temperature display illuminate.

3. Press either the „+“ (WARMER) or „-“ (COLDER) button.
The temperature display switches over and the DESIRED temperature currently set flashes on the temperature display.

4. Set the required temperature by pressing the „+“ (WARMER) or „-“ (COLDER) buttons (see section "Temperature setting buttons"). The temperature display will immediately show the changed setting. With each further press of one of the two buttons, the DESIRED temperature is adjusted by 1°C.

Adjustable temperature range: +3°C to +8°C.

ⓘ **Note:** From a food safety point of view, +5°C for the refrigerator compartment should be considered cold enough as a storage temperature.

5. Once the required temperature has been set, after a short period (approx. 5 sec.) the temperature display will change and again indicate the current ACTUAL temperature inside the fridge. The display will change from flashing to continuous illumination.

The compressor will start and then run automatically.

Information! When the setting is changed, the compressor does not start immediately if automatic defrosting is currently taking place.

ⓘ Goods to be refrigerated can be loaded immediately after switching on, because the storage temperature in the refrigerator is quickly reached.

Downloaded from Fridge-Manual.com Manuals

In the LONGFRESH 0°C compartment the temperature is controlled automatically. It stays constantly at about 0°C, no adjustment is necessary.

Note: The refrigerator compartment is fitted with a fan. This quickly cools food stuffs and ensures optimal distribution of the temperature between the fridge and the LONGFRESH 0°C compartment.
This results in the fan operating at different speeds for different lengths of time. This is quite normal and not a fault with the appliance.

TURBO COOLMATIC

TURBO COOLMATIC Button

The TURBO COOLMATIC function is suited for quick cooling of large quantities of goods in the refrigerator, e.g. drinks and salads for a party.

☞ **1.** The TURBO COOLMATIC function is switched on by pressing the TURBO COOLMATIC button. The yellow light illuminates.

2. The TURBO COOLMATIC function now ensures intensive cooling. A DESIRED temperature of +3°C is automatically selected. The TURBO COOLMATIC function is ended automatically after a period of 6 hours. The originally selected DESIRED temperature is again valid and the compartment will return to. The temperature display shows the ACTUAL refrigerator temperature.

3. The TURBO COOLMATIC function can be ended manually at any time by pressing the TURBO COOLMATIC button again. The yellow light goes out.

Switching off the appliance

☞ To switch off, press the ON/OFF button for approx. 5 seconds. This will result in a countdown from "3" to "1" taking place in the temperature display. On reaching "1" the fridge will switch off. The temperature display will go off.

Note: The appliance cannot be switched on or off if unplugged, or if there is no power being supplied to it. Following connection to the

Downloaded from Fridge-Manual.com Manuals

mains power supply, the appliance returns to the same operating state as before the interruption of main power.

If the appliance is not going to be used for an extended period:

☞ **1.** Remove all refrigerated packages.

2. Switch off the appliance by holding down the ON/OFF button until the display goes off (see above).

3. Remove the mains plug or switch off or disconnect from the electricity supply.

4. Clean thoroughly (see section "Cleaning and Care").

5. Leave the doors open to avoid the build up of odours.

Interior Accessories

Storage shelves

On the bottom of the refrigerator compartment, just above the LONGFRESH 0°C compartment, you can easy place can and bottles in horizontal position. The structure of this area will prevent the bottles and cans from moving around.

The height of the storage shelves can be adjusted:



☞ **1.** To do this pull the storage shelf forward until it can be swivelled upwards or downwards and removed.

2. Please do the same in reverse to insert the shelf at a different height.

Your appliance is equipped with two half-size glass storage shelves.



Storing tall items:

☞ Slide the front half of the Vario storage shelf in another level to the rear. By this means you will gain space to place tall items on the storage shelf below.

Downloaded from Fridge-Manual.com Manuals

Variable Inner Door

The door compartments can be pulled up and removed, and inserted at other positions as needed.

Bottle Holder

Your model is equipped with a bottle holder in the bottle compartment. This is used to prevent individual bottles from falling over and can be slid sideways.



LONGFRESH 0°C compartment

In the LONGFRESH 0°C compartment the temperature is controlled automatically. It stays constantly at about 0°C, no adjustment is necessary.

The constant storage temperature of about 0°C and the relative humidity of between 45 and 90 % provide optimal conditions for the various kinds of food.

You can therefore store a variety of fresh food in the LONGFRESH 0°C compartment, where it will last up to 3 times longer with better quality compared to normal refrigerator compartments.
This allows you to stock more fresh food. Taste, degree of freshness, quality and nutritional values (vitamins and minerals) are well preserved. Loss of weight in vegetables and fruit diminishes. Food yields a higher degree of nutritional value.

The LONGFRESH 0°C compartment is also suitable for defrosting food. In this case the thawed food can be stored up to two days in the LONGFRESH 0°C compartment.

Downloaded from Fridge-Manual.com Manuals

Humidity control



Both drawers can be used according to the desired storage conditions independently of each other with lower or higher humidity.

Regulation for each drawer is separate and is controlled using the slide valve at the front of the drawer.

- **„Dry"**: low air humidity - up to 50 % relative humidity

  This humidity level is reached when both sliders are set into this position and the ventilation openings are wide open.

- **„Humid"**: high relative humidity - up to 90%

  This humidity level is reached when both sliders are set in this position and the ventilation openings are closed. Humidity is kept and can not escape.

Drawers

The wire shelves inside the drawers permit that air can circulate freely and consequently a better conservation of foods.

The compartment has stops to prevent the drawers from falling out when fully extended.
To remove the drawers (e.g. for cleaning purposes), pull them out as far as the stops, lift and extract.



Downloaded from Fridge-Manual.com Manuals

Correct storage

The refrigerator compartment is fitted with a fan. This quickly cools food stuffs and ensures optimal distribution of the temperature between the fridge and the LONGFRESH 0°C compartment.

The following can be conserved in the refrigeration compartment:
- beverages, preserves, jars, bottles;
- baked goods, prepared foods;
- products with short-term expiration;
- foods which are not suitable for conservation at the temperature of the LONGFRESH 0°C compartment.

Tips:

- Do not place warm foods or uncovered liquids in the refrigerator.
- Place foods in such a way that air can circulate freely.
- Keep butter and cheese in the special compartment to guarantee their consistency and aroma.
- Foods, and especially salad, must be kept well covered or packaged in such a way that they do not dry out and that their flavours and fragrances remain unchanged.

The following are suited for packaging:
- Polyethylene airtight bags and wraps;
- Plastic containers with lids;
- Special plastic covers with elastic;
- aluminium foil.

- High-proof spirits should only be conserved tightly closed and in a vertical position.
- Do not keep explosive or flammable materials in the refrigerator.

Conserve in the LONGFRESH 0°C compartment all foods which are suited to it.

Storage time in the LONGFRESH 0°C compartment for fresh food

Type of food	Air humidity adjustment	Storage time
Onion	"dry"	up to 5 months
Butter	"dry"	up to 1 month
Large pork cuts	"dry"	up to 10 days

Downloaded from Fridge-Manual.com Manuals

Type of food	Air humidity adjustment	Storage time
Beef, venison, small pork cuts, poultry	"dry"	up to 7 days
Tomato sauce	"dry"	up to 4 days
Fish, shellfish, cooked meat products	"dry"	up to 3 days
Cooked seafood	"dry"	up to 2 days
Salad, vegetables Carrots, herbs, Brussels sprouts, celery	"humid"	up to 1 month
Artichokes, cauliflower, chicory, iceberg lettuce, endive, lamb's lettuce, lettuce, leeks, radicchio	"humid"	up to 21 days
Broccoli, Chinese leaves, kale, cabbage, radishes, Savoy cabbage	"humid"	up to 14 days
Peas, kohlrabi	"humid"	up to 10 days
Spring onions, asparagus, spinach	"humid"	up to 7 days
Fruit (*) Pears, dates (fresh), strawberries, peaches (*)	"humid"	up to 1 month
Plums (*), rhubarb, gooseberries	"humid"	up to 21 days
Apples (not sensitive to cold), quinces	"humid"	up to 20 days
Apricots, cherries	"humid"	up to 14 days
Damsons, grapes	"humid"	up to 10 days

(*) The riper the fruit, the shorter the storage time

Downloaded from Fridge-Manual.com Manuals

Type of food	Air humidity adjustment	Storage time
Blackberries, currants	"humid"	up to 8 days
Figs (fresh)	"humid"	up to 7 days
Blueberries, raspberries	"humid"	up to 5 days

Cakes containing cream and other kinds of pastry products can be stored in the LONGFRESH 0°C compartment for 2 or 3 days.

Important!

Not to be placed in the LONGFRESH 0°C compartment:

- cold sensitive fruit which have to be stored at cellar or room temperature like pineapple, bananas, grapefruit, melons, mango, papaya, oranges, lemons, kiwi fruit.
- The types of food not mentioned above should be stored in the refrigerator compartment (e.g. all sorts of cheese, cold cuts, etc.).

The level of air humidity in the drawers depends on the content of humidity in the stored food, vegetable and fruit and on the frequency of door opening

The LONGFRESH 0°C compartment is also suitable for slow thawing of food. In this case the thawed food can be stored in the LONGFRESH 0°C compartment for up to two days.

Tips:

- Pay attention to the freshness of the food, especially on the expiry date. Quality and freshness influence the storage time.
- The whole storage cycle time will depend on the preservation conditions made prior to the final storage in the fridge.
- Food, fruit or vegetables should always be packed or wrapped up before storage.
- Animal food always store packed and dry.
- Food rich in proteins will go bad quicker. This means seafood will spoil before fish which in turn will spoil before meat. While storing food in a 0°C compartment storage time for that kind of food can be increased by up to three times as well without loss on quality.
- All food stored in a 0°C compartment should be taken out of the drawers roughly 15-30 min before consumption, particularly fruit

Downloaded from Fridge-Manual.com Manuals

and vegetables to be consumed without any additional cooking process. Allowing fruit and vegetables to return to room temperature will improve the texture and flavour.

Defrosting

The fridge defrosts automatically

Defrosting of the fridge compartment is automatic.
During defrosting, the air re-circulation fan is off.
The water that forms flows into a recipient on the compressor and evaporates. This recipient cannot be removed.

Cleaning and Care

For hygienic reasons the appliance interior, including interior accessories, should be cleaned regularly.

Warning!

- The appliance must not be connected to the mains during cleaning. Danger of electrical shock! Before cleaning switch the appliance off and remove the plug from the mains, or switch off or turn out the circuit breaker or fuse.
- Never clean the appliance with a steam cleaner. Moisture could accumulate in electrical components, danger of electrical shock! Hot vapours can lead to the damage of plastic parts.
- The appliance must be dry before it is placed back into service.

Important!

- Ethereal oils and organic solvents can attack plastic parts, e.g.
  – lemon juice or the juice from orange peel;
  – butyric acid;
  – cleansers which contain acetic acid.
  Do not allow such substances to come into contact with appliance parts.
- Do not use any abrasive cleansers.

☞ **1.** Remove the food from the refrigerator. Store it in a cool place, well covered.

Downloaded from Fridge-Manual.com Manuals

2. Switch the appliance off and remove the plug from the mains, or switch off or turn out the circuit breaker or fuse.
3. Clean the appliance and the interior accessories with a cloth and luke-warm water with a little bicarbonate of soda added (5ml to 0,5 litres of water).
4. After cleaning wipe with clean water and rub dry.
5. After everything is dry reconnect the appliance to the electricity supply.

The lowest shelf, dividing the cooler compartment from the LONGFRESH 0°C compartment can be removed for cleaning. To remove pull out the shelf straight.

The cover plates above the drawers in the 0°C compartment can be taken out for cleaning. To make sure fully functionality of the LONGFRESH 0°C compartment the cover must be put back in their original position after cleaning.

Energy Saving Tips

- Do not install the appliance near cookers, radiators or other sources of warmth. High ambient temperatures cause longer, more frequent operation of the compressor.
- Ensure sufficient air circulation and exhaust at the appliance base and at the back wall of the appliance. Never cover air vent openings.
- Do not place warm foods into the appliance. Allow warm foods to cool first.
- Only leave door open as long as necessary.
- Do not set temperature any colder than necessary.

What to do if ...

Correcting Malfunctions

A malfunction may be caused by only a minor fault that you can rectify yourself using the following instructions. Do not perform any other work on the appliance if the following information does not provide assistance in your specific case.

Downloaded from Fridge-Manual.com Manuals

Important! Repairs to refrigerators/freezers may only be performed by competent service engineers. Improper repairs can give rise to significant hazards for the user. If your appliance needs repairing, please contact your specialist dealer or our local Customer Service.

Symptom	Possible Cause	Remedy
Appliance does not work.	Appliance is not switched on.	Switch on the appliance.
	Mains plug is not plugged in or is loose.	Insert mains plug.
	Fuse has blown or is defective	Check fuse, replace if necessary.
	Socket is defective.	Mains malfunctions are to be corrected by an electrician.
Appliance cools too much.	Temperature is set too cold.	Press „+" (WARMER) button.
The refrigerator and/or freezer compartment temperature is insufficient.	Temperature is not properly adjusted.	Please look in the "Starting up and Temperatur regulation" section.
	Door was open for an extended period.	Open the door only as long as necessary.
	A large quantity of warm food was placed in the appliance within the last 24 hours.	Press TURBO COOLMATIC button.
	The appliance is near a heat source.	Please look in the "Installation location" section.
Interior lighting does not work.	Light bulb is defective.	Please look in the "Changing the light bulb" section.
The compressor does not start immediately after pressing the TURBO COOLMATIC button, or after changing the temperature setting.	This is normal, no error has occurred.	The compressor starts after a period of time.

Downloaded from Fridge-Manual.com Manuals

Changing the light bulb

Warning! There is a risk of electric shocks! Before changing the light bulb, switch off the appliance and unplug it, or disconnect from the mains supply.
Light bulb data: 220-240 V, max. 25 W

1. To switch off, press the ON/OFF button until the mains power light extinguishes.
2. Unplug the mains plug.
3. To change the light bulb, press on the rear hook and at the same time slide the light bulb cover in the direction indicated by the arrow.
4. Change the faulty light bulb.
5. Refit the light bulb cover.
6. Put the refrigerator back into operation.



Customer Service

If you cannot find the remedy for a malfunction in these operating instructions, please contact your dealer or our customer service department. Addresses and telephone numbers are listed in the accompanying booklet "Guarantee Conditions/Customer Service Locations". Selective ordering of replacement parts can save unnecessary travel and costs. For this reason always provide the following appliance information:

- Model Name
- Model Number (PNC)
- Serial Number (S-No.)

This information can be found on the serial plate in the interior at the left of the appliance. We recommend that you enter this information here, so that it is handy if needed.
Note: The customer bears the costs of unjustified customer service calls even during the guarantee period.

Downloaded from Fridge-Manual.com Manuals

Noises during Operation

The following noises are characteristic of refrigeration appliances:

- **Clicks**
  Whenever the compressor switches on or off, a click can be heard.
- **Humming**
  As soon as the compressor is in operation, you can hear it humming.
- **Bubbling/Splashing**
  When refrigerant flows into thin tubes, you can hear bubbling or splashing noises. Even after the compressor has been switched off, this noise can be heard for a short time.
- **Rustling**
  Your appliance is equipped with a dynamic air ventilation system. To ensure optimal cooling performance in the refrigerator and LONGFRESH 0°C compartment the fan is operates with various power levels. This results in the fan operating at different speeds for different lengths of time. This is quite normal and not a fault with the appliance.

Regulations, Standards, Guidelines

This appliance was designed for household use and was manufactured in accordance with the appropriate standards. The necessary measures in accordance with appliance safety legislation regulations (GSG), accident prevention regulations for refrigeration appliances (VBG 20) and the regulations of the German Society of Electrical Engineers (VDE) were observed in the manufacture of this appliance.
The refrigerant circuit has been checked for leaks.

CE This appliance is in accordance with the following EU guidelines:

- 73/23/EWG dated 19 February 1973 - low voltage guidelines.
- 89/336/EWG dated 3 May 1989
  (including guideline change notice 92/31/EWG) - EMV guideline
- 94/2/EG dated 21.01.1994 - Directive on Energy Labelling
- 96/57 EG dated 3.9.1996 - Energy Efficiency Requirements of Household Electric Refrigerators, Freezers and Combinations Thereof.

Downloaded from Fridge-Manual.com Manuals

Technical terminology

- **Refrigerant**
  Liquids that can be used to a generate a cooling effect are known as refrigerants. They have a relatively low boiling-point, indeed so low, that the warmth from the food stored in the fridge or freezer can cause the refrigerant to boil and vaporise.
- **Refrigerant Circuit**
  Closed circulation system that contains the refrigerant. The refrigerant circuit comprises primarily of an evaporator, a compressor, a condenser and pipe work.
- **Evaporator**
  The refrigerant is evaporated in the evaporator. Similar to all other liquids, refrigerant requires heat to evaporate. This heat is removed from the interior of the appliance, as a result the interior is cooled. The evaporator is therefore located inside the appliance or placed in foam immediately behind the inner wall and thus not visible.
- **Compressor**
  The compressor looks like a small drum. It is driven by a built-in electric motor and is mounted on the base of the appliance at the rear. The task of the compressor is to draw in vaporised refrigerant from the evaporator, to compress it, and to pass it on to the condenser.
- **Condenser**
  The condenser normally has the form of a grid. The refrigerant compressed in the compressor is liquefied in the condenser. During this process, heat is released to the surrounding air at the surface of the condenser. The condenser is mounted on the base of the appliance.

Downloaded from Fridge-Manual.com Manuals

Downloaded from Fridge-Manual.com Manuals

From the Electrolux Group. *The world's No.1 choice.*

Die Electrolux-Gruppe ist der weltweit größte Hersteller von gas- und strombetriebenen Geräten für die Küche, zum Reinigen und für Forst und Garten. Jedes Jahr verkauft die Electrolux-Gruppe in über 150 Ländern der Erde über 55 Millionen Produkte (Kühlschränke, Herde, Waschmaschinen, Staubsauger, Motorsägen und Rasenmäher) mit einem Wert von rund 14 Mrd. USD.

From the Electrolux Group. *The world's No.1 choice.*

The Electrolux Group is the world's largest producer of powered appliances for kitchen, cleaning and outdoor use. More than 55 million Electrolux Group products (such as refrigerators, cookers, washing machines, vacuum cleaners, chain saws and lawn mowers) are sold each year to a value of approx. USD 14 billion in more than 150 countries around the world.

AEG Hausgeräte GmbH
Postfach 1036
D-90327 Nürnberg

http://www.aeg.hausgeraete.de

© Electrolux plc 2005

Änderungen vorbehalten

2222 722-57 -00- 10/06

Subject to change without notice

Downloaded from Fridge-Manual.com Manuals